

Mounting Instruction

WITH SET-UP DATA

SHOCK ABSORBER PB743 REAR
for Polaris FS/FST Touring



Before installing this product, check the contents of the kit listed below. If anything is missing, please contact your nearest Öhlins dealer.

Kit Contents

Art. No.	Pcs.
Shock absorber	PB743 1
Öhlins Sticker	00192-01 2
Owner's Manual	1

During storage and transportation, especially at high ambient temperature, some of the oil and grease used for assembling may run out and stain the packaging. This is in no way detrimental to the product, wipe off the excessive oil/ grease with a cloth.

Before installing this product, read the Öhlins Owner's Manual!



© Öhlins Racing AB. All rights reserved. Any reprinting or unauthorized use without the written permission of Öhlins Racing AB is prohibited. Printed in Sweden.



Öhlins Racing AB, Box 722, S-194 27 Upplands Väsby, Sweden.
Phone +46 8 590 025 00 Fax +46 8 590 025 80
www.ohlins.com

MOUNTING INSTRUCTIONS

1

Raise the rear end of the snowmobile so that the track is off the ground. Refer to the vehicle service manual when installing the shock absorber.

WARNING!

Make sure the vehicle is securely positioned so that it will not tip while you are working!

2

Release the rear suspension spring preload. Refer to the vehicle service manual.

3

Install the Öhlins shock absorber. The cylinder head should be toward the front and facing down. See figure. Use the screws and nuts provided in this kit.

Make sure that all bolts are tightened to the correct torque and that nothing fouls or restricts movement of the shock absorber when the suspension is fully compressed or extended.

4

Read more about the shock absorber in your Öhlins Owner's Manual.

3

The Öhlins shock absorber should be installed with the cylinder head toward the front and down.

NOTE!

